




Backwall Instructions


1. Unpack the frame and accessories from the storage bag.



2. Have two people pull gently outward and open on either side of the frame.
IMPORTANT: Using too much force to open the backwall can break the frame.



3. Once the frame has expanded fully push the two sides of a hook on each cross section so that you can hook the frame secured firmly in place.



4. Repeat steps 1-3 to assemble the second half of the backwall. Attach the graphic print to the velcro frame.

